



Thermal Imaging Monocular Wild Series User Manual









Content

About This Manual	05
Regulatory Information	06
1. Introduction	07
1.1 Device Description	07
1.2 Features	07
1.3 Application Scenarios	07
1.4 Appearance	08
2. Packing List	09
3. Operation Guide	10
3.1 Charging	10
3.2 Power on/off	11
3.3 Buttons and Controls	11
3.3.1 Buttons Combinations and Introduction	11
3.3.2. Lens Adjustment	12
3.3.3 Joystick Operation	12
3.3.3.1 Zoom	12

3.3.3.2 AI Ranging and Laser Rangefinder	13
3.3.3 Pseudo Color Switch	13
3.3.3.4 Target Outline Mode	14
3.3.4 Capture/Record	15
3.4 Set	15
3.4.1 Setting	15
3.4.2 System Setting	17
3.4.3 Network Connection	25
3.4.3.1 App Download	26
3.4.3.2 Connect via Hotspot	26
3.4.4 File Management	27
3.5 External Video & Data Reading	29
3.6 System Software Upgrade	29
4. Technical Data	31
4.1 Product Size & Drawing	31
4.2 Specifications	33

About This Manual

COPYRIGHT © 2024 ThermTec Technology Co., Ltd. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of ThermTec Technology Co., Ltd. or its subsidiaries (hereinafter referred to as "ThermTec"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of ThermTec. Unless otherwise stipulated, ThermTec does not make any warranties, guarantees or representations, express or implied, regarding to the Manual. This Manual is applicable to Thermal Imaging Monocular.

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons.



Regulatory Information

CE

This product and, if applicable, the supplied accessories are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Radio Equipment Directive 2014/53/EU, the EMC Directive 2014/30/EU, the RoHS Directive 2011/65/EU.



This product and - if applicable - the supplied accessories too are marked with "UKCA" and comply therefore with the following directives: Radio Equipment Regulations 2017, Electromagnetic Compatibility Regulations 2016, Electrical Equipment (Safety) Regulations 2016, the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012.



This product and - if applicable - the supplied accessories too are marked with "RoHS" and comply therefore the requirements of Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment ("RoHS recast" or "RoHS 2").



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.



Directive 2006/66/EC and its amendment 2013/56/EU (Battery Directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.



1.1 Device Description

Wild Series Thermal Imaging Monocular is designed with a NETD less 18mk, 12µm uncooled infrared detector and 1024x768 OLED high-definition display. With AI image recognition algorithm, it gets clear views under various lighting conditions, even in complete darkness, providing reliable and high-quality visual images for night activities. It can also view the moving target and meet the outdoor conditions. The apparatus can be widely used for searching and rescuing, hunting, etc.

1.2 Features

- 12μm uncooled infrared detector, NETD less than 18mk;
- 1x--4x continuous digital zoom;
- LRF-Boost, AI and laser rangefinder combination;
- Various pseudo colors;
- Joystick control design, wheel focusing realizes one-hand operation;
- Detector anti-burn mechanism;
- Super large aperture offers better temperature radiation capturing capability;
- 1024*768 resolution with 0.39 inch OLED display;
- Up to 10h continuous working for lithium battery;

1.3 Application Scenarios

- Animal Observation
- Outdoor Adventure
- Security Law Enforcement
- Emergency Search and Rescue

1.4 Appearance

- 1 Lens cover
- 2 Power button
- 3 Focusing knob
- (4) Joystick
- **(5)** Capture/Record button
- 6 Diopter knob
- (7) Eyepiece cover
- (8) Compartment of replaceable battery
- (9) Type-C port
- (10) Laser module









3.1 Charging

Here are two methods we could take to charge the device. Device Charging and Battery Charging.

Device Charging:

Connect the device and power adaptor directly with a type-C cable to power on the device. Alternatively, connect the device and PC to export files. Follow the below steps to charge the battery:



- Lift the cover from the USB port.
- Plug the cable provided into the USB port.
- Plug the opposite end of the cable into a USB power source.

Battery Charging:

Wild series have adopted replaceable and changeable battery design. The batteries could be taken off and charged directly, from which dramatically improves the device life.



Note:

- The battery should be fully charged prior to use.
- The battery is supposed to be taken out for long time non-using occasions.

3.2 Power on/off

Press and hold the power button to power on/power off the device.



3.3 Buttons and Controls

3.3.1 Buttons Combinations and Introduction

Before entering the main menu										
	Sh	ort Press		Long Press			Double Press			
Power Button	Star	ndby Mode		On/Off			N/A			
Capture Button	Capture			Record			N/A			
	Up	Down	Left	Left Right Center					nter	
Joystick			Al Range		Short Push	Long P	ush	Brief C	lick	Double Click
JOJSKICK	Zoom in	Zoom out	t finder		Pseudo Switch		Outline Mode		ation	Menu
After entering the main menu										
	Up	D	own	n Left			Right Short Pre			hort Press
Joystick	Move uj	o Mov	ve down		Exit sub-menu Open S		n Suk	n Sub-menu		Confirm

3.3.2. Lens Adjustment

Diopter Adjustment

Looking through the eyepiece, adjust the position of diopter level to optimize the image sharpness on the OLED display.



Objective Lens Focusing

Manually adjust the objective lens focus when you can't see the scene clearly.



3.3.3 Joystick Operation

3.3.3.1 Zoom

Push the joystick to the front to zoom in, vice versa.





3.3.3.2 AI Ranging and Laser Rangefinder

Push the joystick to the left to activate AI rangefinder or laser rangefinder.



Note: the laser rangefinder is only available for Wild LRF series.

3.3.3.3 Pseudo Color Switch

Brief push joystick to right to switch pseudo colors.









There are totally six pseudo colors (white hot, black hot, red hot, green, golden, violet) for user choice.













White

Black

Golden

Green

Violet

3.3.3.4 Target Outline Mode

Long push the joystick to right to enter the target outline mode.





3.3.4 Capture/Record

Image Capturing

Press Capture button to take photos. Then the photo icon in the upper left corner will flash once.



3.4 Set

Select setting and double-click the joystick to enter setting menu. Note: Select by moving the joystick, and short press the joystick to confirm the selection.

3.4.1 Setting

Image Capturing

Press to enter the Imaging Setting menu. There are five sub-menus for image setting, which are "Image Mode", "Sharpness", "Denoise", "Brightness" and "Contrast".

Video Recording

Press and hold Capture button to take videos. Then the recording icon starts flashing in the upper left corner, and the recording starts timing. Press and hold again to stop recording.





Image Settings								
	Forest	The image details would be enhanced in a way.						
Sharpness	0-10	Adjust image sharpness to make the image edge sharper. The recommended value is 5.						
Denoise	0-10	Adjust image noise to make the image cleaner. The recommended value is 5.						
Brightness	1-10	Adjust image brightness to make the image brighter. The recommended value is 5.						
Contrast	1-10	Adjust image contrast to make the target more prominent in the image. The recommended value is 5.						

3.4.2 System Setting

Press joystick to confirm **Setting** to enter the System Setting menu. Select by moving the joystick, and short-press the joystick to confirm the selection.





Detector anti-burn function, it could be set by on/off.

Anti-Burn



Once it detects harmful rays to the detector, the system will enable protection automatically.

EIS	Electronic Image Stabilization	Correction OSD Ant: thum SS Ant: thum SS Binditixat System Menu Set	Electronic Image Stabilization. It could be switched on/off in the system setting.
Tracking		Correction GSD Anti-thum es Pic Ranging Dis Bind/Joiet System Menu Set	Turn on heat tracking to mark the target with the highest temperature in real time in the screen.
РІР	Picture in picture	Correction So Anti-Baine So Ranging Dia Bindfowet System Menu Set	In the picture, the image is 2x enlarged from the center of the cross.













EIS function: Turn on the EIS function to reduce the impact of body shaking on the image and keep the image stable when observing distant targets.

3.4.3 Network Connection

Select Internet icon to and press joystick to enter the Network Connection menu.



3.4.3.1 App Download

You may download the "ThermTec Outdoor" APP through the QR code shown on the packing box, user manual or below.



3.4.3.2 Connect via Hotspot

• Turn on device's hotspot.



- Connect mobile client with device's hotspot.
- After the connection, you could control devices freely with APP (ThermTec Outdoor).

3.4.4 File Management

Select Files and press the joystick to enter the Files. Select the image and video sub-menus to view the images and videos and play the videos.

Image Viewing

• Press the joystick to enter image files.



• After selecting a certain image, press joystick to access further operations of the image, we could delete it, check next one or delete all the images.

Back

2023-10-08_00-01-58_1024.jpg 2023-10-08_00-01-48_1024.jpg 2023-10-08_00-01-57_1024.jpg 2023-10-08_00-01-47_1024.jpg 2023-10-08_00-01-56_1024.jpg 2023-10-08_00-01-46_1024.jpg 2023-10-08_00-01-55_1024.jpg 2023-10-08_00-01-44_1024.jpg 2023-10-08_00-01-54_1024.jpg 2023-10-08_00-01-44_1024.jpg 2023-10-08_00-01-55_1024.jpg 2023-10-08_00-01-42_1024.jpg 2023-10-08_00-01-55_1024.jpg 2023-10-08_00-01-42_1024.jpg 2023-10-08_00-01-55_1024.jpg 2023-10-08_00-01-41_1024.jpg 2023-10-08_00-01-55_1024.jpg 2023-10-08_00-01-40_1024.jpg 2023-10-08_00-01-50_1024.jpg 2023-10-08_00-01-40_1024.jpg 2023-10-08_00-01-49_1024.jpg 2023-10-08_00-01-40_1024.jpg

⊙ 25 🕩 1.0X 🚯 🛄 奈 💽 14:54



Video Viewing

- Select Record and press joystick to enter video files.
 Choose a certain video and press joystick to check the video.



• Further operations could be accessed here, we could delete it, check next one, pause the video or delete all the videos.



3.5 External Video & Data Reading

Video Output

Use the given AV video cable to output analog video.

Data Reading

When external display is connected, the OLED of the device automatically turns off. Power on the device, use a type-C USB cable to connect with the computer to read the video and image data in the memory.

Note: Videos, images and rav videos taken will be saved separately in folders named "record", "image" and "rav"

3.6 System Software Upgrade

Wild series thermal imaging monocular supports **"ThermTec Outdoor" APP**, which allows you to transmit the image from the thermal imager to the smartphone or tablet via Hotspot in real time mode.

Upgrading via APP

- Open ThermTec Outdoor APP.
- Turn on the hotspot of the device, and connect it with the Mobile phone.
- Select Update on the menu options.
- The downloading and upgradation would be a continuous process if there is an update.
- After finishing the update, the device will reboot.

Upgrading via PC

• Please download corresponding upgrading package from official website. **www.thermeyetec.com**. Connect the device to PC via Type-c data cable.



• Copy the related updating firmware to the storage file of Wild. Press joystick to select Update icon, and the system will prompt "Update".



• Enter version to check firmware version.



4.1 Product Size & Drawing



Note: Wild325, Wild335 and Wild635 are of the same size.



Note: Wild335L & Wild635L are of the same size.

4.2 Specifications Specifications - Wild

Model	Wild325	Wild335	Wild635	Wild650	Function					
	Microbolometer				Photo/video playback	Photo/video Yes				
Resolution	384	x288	640	x512	Language	Multiple-languages				
Pixel Pitch		12	um		Built-in Memory	64GB				
NETD		18mk(@300k		PIP	Yes				
Spectral range		8-14	~		Al Distance Measurement		Ye	S		
					Heat Track		Ye	S		
Frame rate	50HZ				Real-time Notification		Ye	S		
Detection Range	1300m	1800m	1800m	2600m	OSD Recording		Ye	s		
	Optics				Burn prevention	Yes				
Objective lens	25mm/F0.8	35mm/F0.8	35mm/F0.9	50mm/F0.9	EIS Yes					
Field of view	10.5° x 7.9	7.5° x 5.6°	12.5° x 10°	8.8° x 7.0°	Battery					
Magnification	2.4X	3.3X	2.0X	2.8X	Internal battery Replaceable and Rechargeable Li-ion Battery (18650x1)				y (18650x1)	
Digital Zoom		1-4X contin	uous zoom		Battery life	10			8h	
Eye relief		40r	10.100				Interface			
Lyerener		401	nin		Type-C	Supports battery charging, data transfer, USB video output				
Exit pupil		6n	nm		Hotspot	Yes, App remote control				
Diopter		±	5D			E	nvironment			
		Display			Working temperature		-20°C~	+50°C		
Туре		AMC	DLED		Protection Level		IP	67		
Resolution	1024x768			Weight, g	470±5g 485±5g 475±5g 510			510±5g		
Display size	0.39 inch				Size,mm				190.2(L)x76.3(W) x65.6(H)	
Color palette						Accessories				
color palette	6				External Cable	USB cable				
Image mode	Forest/Outline				Other Accessories	Palm strap/Protective bag/Non-dust cloth and etc.				

Specifications - Wild

			Wild650L	Language		Multiple-languages		
	Microbolometer				64GB			
Resolution	384x288 640x512			PIP	Yes			
Pixel Pitch	30 1/200		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	LRF Boost	Yes			
		12µm		Heat Track	Yes			
NETD		18mk@300k		Real-time Notification	Yes			
Spectral range		8-14µm		OSD Recording				
Frame rate		50HZ		Burn prevention	Yes Yes			
Detection Range	1800m	1800m	2600m	EIS		Yes		
	Op	otics			Batt	tery		
Objective lens	35mm/F0.8 35mm/F0.9 50mm/F0.9			Internal battery	Replaceable and Rechargeable Li-ion Battery (18650x1)			
Field of view	7.5° x 5.6° 12.5° x 10° 8.8° x 7.0°		Battery life	10h 8h				
					Interface			
Magnification	3.3X 2.0X 2.8X			Type-C	Supports battery charging, data transfer, USB video output			
Digital Zoom		1-4X continuous zoon	n	Hotspot		s, App remote contro	l	
Eye relief 40mm				Working	Enviro	nment		
Exit pupil	Exit pupil 6mm				-20°C~+50°C			
Diopter		±5D		Protection Level	IP67			
	Die	play		Weight, g	515±5g	505±5g	540±5g	
Туре	DIS	AMOLED		Size,mm	190.2(L)×	69.3(W)x77.1(H)	190.2(L)x76.3(W) x84.6(H)	
Resolution					Access	sories		
	1024x768			External Cable	USB cable			
Display size	0.39 inch			Other Accessories				
Color palette	r palette 6				Laser Rangefinder			
Image mode	node Forest/Outline			Safety Class	Class 1			
	Fun	ction		Wavelength	905nm			
Photo/video Yes			Range	1000m ±1m				





ThermTec Technology Co., Ltd.

Email: info@thermeyetec.com Web: www.thermeyetec.com

COPYRIGHT © 2023 ThermTec Technology Co., Ltd. ALL RIGHTS RESERVED.