



SWIVEL STUD ADAPTOR INSTALLATION



M-LOK® MOUNT INSTALLATION



Position the T-Nut as shown to the left and correctly seat the base into the corresponding M LOVE the base into the corresponding M-LOK® slots. Make sure the base is seated evenly.

While holding the base firmly in place, use the supplied Hex wrench to turn the two Hex screws clockwise until both M-LOK® T-Nuts are perpendicular to the M-LOK® Slots and begin to engage the handguard. Continue until tightened. Recommended torque value: 30 in-lb.

Loosen the thumb nut enough for the mount's squared cross bolt to seat evenly into the desired Picatinny slot. Once seated, securely tighten the thumb nut.

PICATINNY MOUNT INSTALLATION



PANNING AND TILTING



Left/Right Tilting Fine-tunable tension adjustment lever

Multi-axial tilting allows for 15 degree tilt structure of the bipod base forward, rearward, left and right.

3 POSITION FOLDING

allows full 360 degree

rotation.



Press down and hold the Posi-lock release

LEG EXTENSION/RETRACTION

is fully released by turning it

counter-clockwise.





Make sure the Locking Thumb Wheel to any location in between notches. Tighten the Locking Thumb Wheel by turning it clockwise to lock the leg.

Extend the bipod leg by pulling it out of the leg housing. Set it at any of the Locking Thumb Wheel first. Press down pre-cut extension notches. Or, extend the Leg Retraction Clamp before you push the extended leg upward into the housing.





